



CÉLINE WRIGHT

PARIS


---

## PARIS BY CELINE WRIGHT- LAMPE A POSER

Fiche technique / Notice de montage

Assembly Notice

---



### PARIS - LAMPE À POSER

- 1 lampe LED Eco Halogène type G9 - 200 Lumen - 3000 Kelvin
- Puissance max : 2 Watt - Tension : 230V €€
- Non dimmable
- Matières : Abat-jour en papier japonais, structure légère en acier blanc, câble alimentation cristal , longueur 2m, interrupteur transparent.
- Entretien : Épousseter régulièrement avec un plumeau naturel ou une micro fibre.

Une lumière de Paris signée par Céline Wright.

Paris qui a vu naître des créations insolites et spectaculaires comme la Tour Eiffel ; Paris, la ville des artistes qui, à toutes époques ont peint, écrit, dessiné, leur vision de Paris, la ville des lumières.

### PARIS - TABLE LAMP

- 1 lamp LED Eco Halogen type G9 - 200 Lumen - 3000 Kelvin
- Power max : 2 Watt - Voltage : 230V €€
- Not dimmable
- Materials: Lamp shade diameter made with japanese paper, light white steel structure. Transparent electric cord, length 2m, transparent switch.
- Maintenance : Dust regularly with a feather duster or a microfiber.

Paris by Celine Wright

An homage to Paris signed by Celine Wright.

Paris, which has seen the birth of unusual and spectacular creations like the Eiffel Tower ; Paris the city of artists who, at each époque have painted, written, and drawn their vision of Paris, the city of lights.

## INSTALLATION DU LUMINAIRE

- Déballez délicatement le luminaire.

## MONTAGE DE L'ABAT-JOUR

- Fixer l'ampoule. (figure 1)
- Fixer la structure dans l'abat jour à l'aide des aimants. (figure 2)

NOTE: POUR CHANGER L'AMPOULE, TENIR LA DOUILLE D'UNE MAIN ET CHANGER L'AMPOULE AVEC L'AUTRE MAIN.  
ATTENTION RISQUE DE BRÛLURE SI L'AMPOULE EST CHAUDE.

## LAMP SET UP

- Delicately take out the lamp from its packaging.

## LAMP SHADE SET UP

- Fix the bulb. (fig 1)
- Slide the electrical structure inside the shade and fix it with the magnet and the metallic disc. (fig 2)

NOTE TO CHANGE THE BULB, HOLD THE FITTING WITH ONE HAND AND CHANGE THE BULB WITH THE OTHER HAND.




figure 1




figure 2

